


5. Installation instructions

5.1 Installation within a control cabinet

[illegible]





C CAN_L
CAN_H



